

# TB-1204 — Macro-Synthetic Fiber Reinforcement Technical Bulletin

## Mix Proportioning, Dispensing, Mixing, Placing and Finishing

Macro-synthetic fiber reinforcement imparts toughness, impact and fatigue resistance to concrete while also reducing plastic shrinkage cracking. Typical macro-synthetic fiber reinforced concrete (FRC) applications include commercial and industrial flooring and elevated composite decks. Slight mix design, dispensing, placement and finishing modifications may be required when incorporating macro-synthetic fibers into a concrete mixture, particularly at higher dosage rates. Batching, mixing, delivery and sampling of macro-synthetic FRC should be done in accordance with ACI 304R-00 (Guide for Measuring, Mixing, Transporting, and Placing Concrete), ASTM C1116 (Fiber-Reinforced Concrete and Shotcrete) and ACI 544.3R-08 (Guide for Specifying, Proportioning, and Production of Fiber-Reinforced Concrete). Consult with your local GCP Applied Technologies sales representative for additional usage and application information for GCP's macro-synthetic fibers, STRUX®90/40 and STRUX®BT50.

## Dispensing

Macro-synthetic fibers are engineered to have superior dispersion properties when dispensed into concrete in both dry batch and central mix concrete plants. The following guidelines should be followed to assure complete dispersion without fiber balling is achieved. It is also recommended that full load size trial batches be conducted prior to job start up.

- (Best) Dispense upfront into empty drum.
- (Good) Tail end addition on concrete in drum revolving at charge speed.
- (Good) Broadcast on aggregate moving up conveyor belt.

## Mixing

Macro-synthetic FRC mixing procedure should, at a minimum, follow ACI 304R-00 4.5.2 guidelines. ACI 304R-00 recommends 70 to 100 revolutions at charge speed initially in plant yard, followed by an additional 30 revolutions at job site prior to discharge to ensure uniformity. Higher macro-synthetic fiber dosage rates may require up to 50% additional mixing at charge speed.

## Placement

Macro-synthetic FRC concrete can be placed using conventional placement techniques including chutes, buckets, buggies, conveying and pumping. Placement of macro-synthetic FRC concrete should be conducted in accordance with ACI 304R-00–section 5.4 with a couple slight modifications. Macro-synthetic FRC concrete may appear to be stiffer and want to “hang together” more than conventional concrete, particularly at higher dosage rates. It is recommended the use of vibratory screeds, laser screeds and/or hand vibrators be used to ease placement and assure adequate consolidation is achieved. Refer to ACI 544.3R-08 Chapter 7 – *Placing and Finishing* for additional recommendations for placing and finishing macro-synthetic FRC.

When screeding and bullfloating macro-synthetic FRC concrete, a substantial number of fibers may remain exposed on the surface. This is expected as a majority of macro-synthetic fibers disappear during the power float and trowel processes. The use of magnesium, rather than wood, bullfloats is recommended. The use of jitterbugs (grade tamper) and/or rollerbugs may help embed exposed macro-synthetic fibers beneath the surface prior to trowelling.

## Mix Proportioning

Minor adjustments to typical slab on ground mix designs may be required when utilizing macro-synthetic fibers to assure ease of use during the batching, mixing, placement and finishing processes. These adjustments may become more critical as macro-synthetic fiber dosage rates increase.

1. Due to their surface area, macro-synthetic fibers will consume some percentage of the mortar fraction, thereby reducing the workability and creaminess of the mix. As detailed in ACI 544.3R-08, it is recommended mix designs be modified to contain **maximum** 55% by volume coarse aggregate content by total volume of aggregates (coarse and fine aggregate). Slight increases in cementitious contents [up to 50 lbs/yd<sup>3</sup> (30 kg/m<sup>3</sup>)] may also be required to achieve required mortar fraction.
2. Some level of slump reduction can be expected when macro-synthetic fibers are incorporated into a mix (see Table 1 below) It is strongly recommended that this loss of workability be restored through the use of a high range or mid range water reducer (instead of water). GCP’s polycarboxylate based ADVA<sup>®</sup> high-range and MIRA<sup>®</sup> mid-range water reducer product lines have a field proven track record of imparting cohesive properties to macro-synthetic FRC.

**Table 1 — Approximate Slump Reduction (in.) (mm) as a function of fiber type and dosage rate**

DOSAGE RATE —	3 LBS/YD <sup>3</sup> (1.8 KG/M <sup>3</sup> )	7 LBS/YD <sup>3</sup> (4.5 KG/M <sup>3</sup> )	15 LBS/YD <sup>3</sup> (9.0 KG/M <sup>3</sup> )
STRUX <sup>®</sup> 90/40	2 in. (50 mm)	4 in. (100 mm)	
STRUX <sup>®</sup> BT50		2 in. (50 mm)	4 in. (100 mm)

## Finishing

**(Broom)** It is expected that broom finished macro-synthetic FRC will have some exposed fibers visible on the surface. While brooming, the brooms should be held at a small angle to the horizontal surface and should be pulled in one direction only.

**(Trowel)** The floating and trowelling process provides the best opportunity to work towards achieving a fiber free or near fiber free macro synthetic FRC surface. Field experiences show excellent quality near flawless fiber free macro-synthetic FRC surfaces can be achieved by following the methodologies below.

- Final finishing operations should be conducted as late as possible (footprints are barely perceived on surface).
- Power float, followed by power trowel finishing technique should be utilized, with more, rather than less, passes made.
- Float blades and finish blades should be kept as FLAT as possible, particularly during initial passes.

[gcpat.com](http://gcpat.com) | North America Customer Service: 1 877-4AD-MIX1 (1 877-423-6491)

We hope the information here will be helpful. It is based on data and knowledge considered to be true and accurate and is offered for consideration, investigation and verification by the user, but we do not warrant the results to be obtained. Please read all statements, recommendations and suggestions in conjunction with our conditions of sale, which apply to all goods supplied by us. No statement, recommendation, or suggestion is intended for any use that would infringe any patent, copyright, or other third party right.

STRUX, ADVA, and MIRA are trademarks, which may be registered in the United States and/or other countries, of GCP Applied Technologies Inc. This trademark list has been compiled using available published information as of the publication date and may not accurately reflect current trademark ownership or status. This product may be covered by patents or patents pending.

© Copyright 2018 GCP Applied Technologies Inc. All rights reserved.

GCP Applied Technologies Inc., 62 Whittemore Avenue, Cambridge, MA 02140 USA.

In Canada, 294 Clements Road, West, Ajax, Ontario, Canada L1S 3C6.

This document is only current as of the last updated date stated below and is valid only for use in the United States. It is important that you always refer to the currently available information at the URL below to provide the most current product information at the time of use. Additional literature such as Contractor Manuals, Technical Bulletins, Detail Drawings and detailing recommendations and other relevant documents are also available on [www.gcpat.com](http://www.gcpat.com). Information found on other websites must not be relied upon, as they may not be up-to-date or applicable to the conditions in your location and we do not accept any responsibility for their content. If there are any conflicts or if you need more information, please contact GCP Customer Service.

Last Updated: 2018-12-28

[gcpat.com/solutions/products/strux-synthetic-macro-fibers/tb-1204-macro-synthetic-fiber-reinforcement](http://gcpat.com/solutions/products/strux-synthetic-macro-fibers/tb-1204-macro-synthetic-fiber-reinforcement)