ENGINEER OF RECORD: PLEASE VERIFY TORSIONAL STABILITY OF BEAM. FOR ATTACHMENT OF OUTRIGGER TO WALL STUDS: TIGHTEN SCREWS, THEN STRUCTURAL BEAM. BACK OFF 1/2 TURN. (BY OTHERS) MARINO\WARE OUTRIGGER VERTICAL SLIDE CLIP. (CONNECTION BY DESIGN)

OUTRIGGER VERTICAL SLIDE CLIP

Marino\WARE 17. FRAMERITE CONNECTORS

WALL STUD