

MARINO\WARE QUICKFRAME CLIP $F_y=50\text{ksi}$.
ATTACH TO JAMB WITH SCREWS
AS REQUIRED.

ATTACH QUICKFRAME CLIP
TO HEADER WITH SCREWS
@ BOTTOM AND TOP AS REQUIRED.

StudRite
CRIPPLE STUD

ATTACH EACH TRACK
TO STUD USING:
SCREWS @ 16"o.c.

FULL HEIGHT
QUICK FRAME
JAMB

ATTACH WITH SCREW
TYP. EACH FLANGE

(1) QUICKFRAME HEADER STUD,
w/(1) RUNNER TRACK.

Marino\WARE

QUICKFRAME HEADER SYSTEM

14. StudRite CURTAINWALL DETAIL