

BLAST-OFF[®]

CONCRETE REMOVER

APPLICATION TIPS

1. Apply with Nox-Crete's Perfect Pump or Power Foamer

For maximum effectiveness, you'll need to use one of Nox-Crete's foamers. These specially designed foamers create a thick foam similar to shaving cream in consistency that clings to vertical and horizontal surfaces.

2. Blast-Off is Temperature Sensitive

The air temperature must be at least 50°F (10°C) when applying Blast-Off, cooler temperatures equate to longer reaction times and lower performance.

3. Give it Time to React

Blast-Off contains a pH-sensitive red dye, once the dye turns clear Blast-Off has fully reacted and it is time to rinse or pressure wash off, this generally takes around 20 minutes.

4. Scrub It

While Blast-Off is working, periodically scrub and agitate the area to be cleaned with a brush. This will remove the outer layer of softened material and allow Blast-Off to further penetrate into the buildup.

5. Stay in the Shade

We recommend applying Blast-Off in the morning or late afternoon/evening when the sun is low or in the shade for best performance.

6. Avoid Letting it Dry

If Blast-Off is allowed to dry prior to rinsing with water a white film will form on the treated surface. To remove the white film, reapply Blast-Off and rinse with water.

7. Multiple Applications are Necessary in Some Situations

After rinsing, if concrete buildup or splatter still remains, reapply Blast-Off and repeat until everything is removed.

8. Remember... It's a Concrete Remover

Blast-Off is a concrete remover and thus will etch and slowly dissolve any concrete surface it is used on including your floor. We recommend cleaning on a gravel or asphalt surface. If you must clean on a concrete surface be sure to saturate the surface with water prior to applying Blast-Off and flood the area with water when done to remove any un-reacted Blast-Off to avoid concrete etching.

9. Clean Everything Big and Small

Blast-Off is great for removing concrete buildup and splatter from large equipment like concrete pavers and screeds, but it can also be used for small equipment. Place small hand tools in a shallow pan containing Blast-Off for 30 minutes to 1 hour to remove buildup.

10. Pressure Wash Works Best

Although you can use a garden hose to rinse Blast-Off from treated surfaces, using a pressure washer between coats will increase effectiveness.