



## HOW-TO GUIDE

# Sikacryl<sup>®</sup> Concrete Patch

### READY-MIX REPAIR PATCH

#### MATERIALS:

- Safety glasses & gloves
- 1 Qt. or 1 Gal. tub of Sikacryl<sup>®</sup> Concrete Patch
- Wire brush
- Margin trowel or putty knife
- Water & clean rag for clean up

#### SITE PREP & PROCEDURE

1. Make sure that all surfaces are clean, sound, dry and free from dirt and loose particles.
2. For best results, use a wire brush to clean off any loose particles or excess dirt or dust.
3. Prior to use, with the trowel or putty knife, stir material thoroughly until a uniform appearance is achieved.
4. Ensure that enough product is pushed into crack or hole to provide coverage. Tool as needed.
5. Areas greater than 1/4 inch deep may require two or more applications.
6. Allow repaired area to fully cure for at least 24 hours minimum before an additional application is installed.
7. Clean up all tools, spills, and excess material immediately with water and clean rag after use.

