



# APPLICATION INSTRUCTIONS

VULKEM®

**350FC/950NF/951NF**

Two-Component, Elastomeric, Waterproof  
Traffic Deck Coating System

---

## 1. PURPOSE

- 1.1 The purpose of this document is to establish uniform procedures for applying the Vulkem® 350FC/950NF/951NF Traffic Deck Coating System. This document describes application procedures for medium and heavy duty requirements. The techniques involved may require modifications to adjust to jobsite conditions. If you have any questions at all about your application, contact your local Tremco Field Sales Representative for specific design requirements.
- 1.2 This document will provide the necessary instructions and troubleshooting for the application of the Vulkem Traffic Deck Coating System to quality for the manufacturer's warranty.

---

## 2. SCOPE

- 2.1 Investigation of the substrate should be performed to determine the type of surface preparation that will need to take place to achieve the appropriate surface profile required for the coating application. Depending on the condition of the concrete, one or more types of surface preparations may be required. Refer to ICRI's Technical Guideline NO. 310.2R-2013 – Selecting and Specifying Concrete Surface Preparation for Sealers, Coatings, Polymer Overlays and Concrete Repair for best practices on selecting the appropriate method of concrete preparation. Thin film and high-build coating applications will require the surface profile, CSP 2-4.

---

## 3. CONDITIONS FOR CONCRETE SURFACES

- 3.1 Concrete shall be water-cured and attain a 4000 psi minimum compressive strength. Moisture content in the concrete must be lower than 4.5% as measured by a Tramex CME 4 Moisture Meter. Depending on concrete construction and job site location, additional concrete testing may be required. Please contact your local Tremco Sales or Technical Representative.
- 3.2 Concrete shall be made free of any laitance which can usually be achieved by shotblasting (preferred method) or sandblasting the surface. For proper methods, refer to ICRI's Technical Guideline No. 310.2R-2013.
- 3.3 Concrete surface shall be properly cleaned so that the surface to receive the coating, sealant or liquid-applied flashing is free of mold, paint, sealers, coating, curing agents, loose particles and other contamination or foreign matter which may interfere with the adhesion. Job site conditions may require the use of a Vulkem Primer.
- 3.4 Shrinkage cracks in the concrete surfaces that are 1/16" (1.6 mm) wide or greater shall be ground out to a minimum 1/4" wide x 1/2" (6 mm x 12 mm) deep and treated according to the instructions in Section 5, Detail Work.
- 3.5 Structural cracks regardless of width shall be ground out to a minimum 1/4" wide x 1/2" (6 mm x 12 mm) deep and treated according to the instructions in section 5, Detail Work.
- 3.6 Spalled areas shall be cleaned and free of loose contaminants prior to repair. Because jobsite conditions vary, it is recommended that you contact Tremco Technical Service or your local Tremco Sales Representative for the best method of repair.
- 3.7 In the event of exposed reinforcing steel, it is recommended that the structural engineer of record be contacted for investigation of the condition and for the best method of repair.
- 3.8 Surfaces shall be made free of defects that may telegraph and show through the finished coating. Surfaces that are rough (fins, ridges, exposed aggregate, honeycombs, deep broom finish, etc.) shall be leveled and made smooth by applying a coat of sand-filled epoxy.
- 3.9 All drains shall be cleaned and operative. Drains shall be lower than the deck surface. Surface shall be sloped to drain to provide positive drainage. Drains should be detailed as instructed below:
  - Cut a 1/4" wide x 1/2" deep (6 mm x 12 mm) keyway into the concrete surface at any point where the coating will have an exposed terminating edge – that is, any point where the coating will end in an open area subject to traffic, for example, at the end of a ramp, around drains, and alongside expansion joints.
- 3.10 If the project is a restoration deck, old sealant and backing material shall be removed. The joint interface will require a thorough wire brushing, grinding, sandblasting, solvent washing and/or primer.

---

## 4. JOBSITE MATERIALS

4.1 Recommended materials and their use are as follows:

**Dymonic® 100:** A one-part, moisture-curing, gun grade polyurethane sealant for use in sealing cracks, control joints, drain detailing, and in forming cants.

**Vulkem 350FC Base Coat:** A two-part, low-odor, low-VOC, fast-curing, polyurethane coating used as the elastomeric waterproofing membrane of the system available in SL (self-leveling) for horizontal applications.

**Vulkem 950NF Top Coat:** A two-part, aromatic, low-odor, VOC-compliant, high-solids polyurethane top coat providing a chemical-resistant, color stable, weatherproof, wear surface.

**Vulkem 951NF Top Coat:** A two-part, aliphatic, low odor, VOC-compliant, high-solids polyurethane top coat providing a chemical- and UV-resistant, color stable, weatherproof wear surface.

**Backer Rod:** A closed-cell polyurethane back-up material used in expansion joints and at the base of cants to prevent three sided adhesion, and to control the depth of the sealant.

**Vulkem Primer #171:** A one-part, film-forming primer to be used on porous surfaces.

**TREMprime® Non-Porous Primer:** A one-part primer for use on metal surfaces.

**Vulkem 191 Primer:** A low VOC compliant one-part porous and interlaminary primer for use in applying a fresh coat of Vulkem coating or sealant after preceding coat has been exposed for long periods of time.

**TREMprime VB Plus Primer:** A two component, modified epoxy primer designed to seal concrete and reduce moisture vapor transmission on concrete slabs with elevated levels of moisture.

**Aggregate:** 16-30 mesh silica sand or alumina oxide, which imparts a textured finish and contribute to slip and wear resistance.

---

## 5. DETAIL WORK

Note: Do not apply sealant or coatings to a frosty, damp or wet surface or when air or surface temperature is below 40 °F (4°C) or the surface temperature is above 110 °F (43 °C). Cure times as stated below are based upon standard ambient conditions of 75 °F (25 °C), 50% RH. A decrease in ambient temperature and humidity will significantly lengthen cure time

- 5.1 Lay a 1/4" (6 mm) diameter backer rod into the corner at the juncture of all horizontal and vertical surfaces such as curbs, wall sections, columns, or penetrations through the deck. Apply a bead of Dymonic 100 1" (2.5 cm) wide over the backer rod. Tool the sealant bead to for a 45° cant. Use sufficient pressure to force out any trapped air and to assure complete wetting of the surface. Remove excess sealant from the deck or wall joint. NOTE: Backer rod is only required for moving joints.
- 5.2 Install a backer rod 1/8" to 1/4" (3 mm to 6 mm) diameter larger than the joint width to all prepared control joints. Set depth of backer rod to control the depth of the sealant. (Depth of sealant is measured from the top of the concrete surface.) Proper depth of sealant is as follows:
  - For joints 1/4" (6.4 mm) to 1/2" (12.7 mm) wide, the width to depth ratio should be equal.
  - Joints 1/2" (12.7 mm) wide or greater that are not expansion joints should have a sealant depth of 1/2" (12.7 mm). The minimum joint size is 1/4" x 1/4" (6.4 mm x 6.4 mm).
  - All cracks and joints shall be sealed with Tremco approved sealant, and tooled flush with the surface. Note: Expansion joints should not be coated over. A full line of expansion joint solutions is available from Tremco Constructions Products Group companies. For treatment of expansion joints, contact your local Tremco Sales Representative.
- 5.3 Allow sealant to cure overnight.
- 5.4 Apply a strip of masking tape or duct tape to the vertical sections, 2" or 3" above the Dymonic 100 Sealant's cant to provide a neat termination of the vertical detail coat.
- 5.5 Pre-mix the Vulkem 350FC base component Part A to assure no settlement of the material is in the bottom of the pail and the color of the material is consistent with no streaks or striations. Vulkem 350FC should be mixed with a spiral paint mixing paddle at a rate of 500 rpm for a minimum of 2-3 minutes. Open, mix and use on pail at a time. Part B must be well shaken prior to mixing with Part A. Empty contents of the curative, Part B into the base, Part A. Carefully mix the two components for 1 to 2 minutes, scrape down the sides of the pail and mix an additional 1 to 2 minutes. Use care to not incorporate air into the product. This could potentially lead to the development of blisters during the coating application. For recommendations on mixer options, contact Tremco Technical Service
- 5.6 Apply 25-mil (.64 mm) thick detail coat of Vulkem 350FC over the treated cant, and extend it to the tape on the vertical surface and 4" (100 mm) onto the horizontal surface. Feather-edge the terminating edge of the Vulkem 350FC detail coat on the horizontal surface so it will not show through the finished coating
- 5.7 Apply a 25-mil (.64 mm) thick detail coat of Vulkem 350FC 6" (150 mm) wide, centered over all untreated cracks, all routed and sealed cracks, and over all cold joints. Feather in terminating edge of detail coat to keep these edges from showing through the finished coating.

---

## 6. COATING APPLICATION

NOTE: Recommended coverage rates are approximate. Sand loading methods and concrete surface profiles may increase the amount of material required to obtain uniform coverage. Please refer to instructions in Section 5.5.

- 6.1 BASE COAT: Apply Vulkem 350FC at 64 ft<sup>2</sup>/gal or 25 wet mils thick to the entire area to be coated, including overall detail coats, but excluding expansion joints. The recommended method of application is with a notched squeegee. Cross-rolling may follow in the event the coating needs to be leveled. Vulkem 350FC can also be applied with a clean, flat-bladed rubber squeegee. Do not apply in excess or to allow to puddle. If backrolling is to take place, use a medium nap (≈ 3/8") roller.
- 6.2 Allow Vulkem 350FC to cure a minimum of 3-4 hr and a maximum of 24 hr. Cure rates depend on temperature. Refer to cure rate guideline in chart at the end of this document.
- 6.3 If the Vulkem 350FC 24 hr re-coat window is exceeded, cleaning and re-priming is required. Please contact Tremco Technical Services for recommendations.
- 6.4 Pre-mix the Vulkem 950NF base component, Part A, to assure no settlement of the material is in the bottom of the pail and the color of the material is consistent with no streaks or striations. Open, mix and use one pail at a time. Empty contents of the curative, Part B, into the base, Part A. Using an appropriate mixer and drill, carefully mix the two components for 1 to 2 minutes, scrape down the sides of the pail and mix an additional 1 to 2 minutes. Use care to not incorporate air in to the product. This could potentially lead to the development of blisters during the coating application. For recommendations on mixer options, contact Tremco Technical Services.
- 6.5 WEAR COAT: Vulkem 950NF wear coat is applied with a squeegee or medium-nap roller at the rate of 133 ft<sup>2</sup>/gal (33 M<sup>2</sup>/L) to yield approximately 12 wet mils (0.30 mm) thickness to the entire deck. For a LIGHT DUTY APPLICATION, apply the Vulkem 950NF wear coat in the driving lanes, ramps, turn areas and ticket areas with a squeegee or medium-nap roller at the rate of 133 ft<sup>2</sup>/gal (33 M<sup>2</sup>/L) to yield approximately 12 wet mils (0.30 mm).
- 6.6 SILICA SAND ADDITION: There are two acceptable methods of applying the silica sand:

### Method A –Sand to Refusal

- 6.6.1 Immediately following the application of the Vulkem 950NF as indicated in 6.5, broadcast to refusal (flood coat) the material with 0.6 to 1.2 mm (16-30 mesh) sized silica sand. Allow application to cure about 2 to 4 hr during ideal ambient temperatures and relative humidity. Before proceeding, sweep or blow off any excess sand. For a LIGHT DUTY APPLICATION, proceed to Step 6.8 TOP COAT. For a MEDIUM DUTY APPLICATION, proceed to Step 6.8 TOP COAT. For a HEAVY DUTY APPLICATION, proceed to Step 6.6.2
- 6.6.2 For a HEAVY DUTY APPLICATION, apply an additional coat of Vulkem 950NF to the driving lanes, ramps, turn areas and ticket areas. Immediately broadcast the sand following with procedure in 6.6.1. Before proceeding with the top coat application sweep or blow off any excess sand. Proceed to Step 6.8 TOP COAT.

### Method B –Backroll

- 6.6.3 Immediately following the application of the Vulkem 950NF as indicated in 6.5, broadcast 0.6 to 1.2 mm (16-30 mesh) sized silica sand into the wet Vulkem 950NF. Broadcast the sand at a rate of 15 to 18 lb/gal (1.8 to 2.2 kg/L) of Vulkem 950NF. Backroll the sand into the coating to ensure all the aggregate is evenly distributed. Allow Vulkem 950NF to cure about 2 to 4 hr during ideal ambient temperatures and relative humidity. For a LIGHT DUTY APPLICATION, proceed to Step 6.8 TOP COAT. For a MEDIUM DUTY APPLICATION, proceed to Step 6.8 TOP COAT. For a HEAVY DUTY APPLICATION, proceed to Step 6.6.4
- 6.6.4 For a HEAVY DUTY APPLICATION, apply an additional coat of Vulkem 950NF to the driving lanes, ramps, turn areas and ticket areas. Immediately following the application of the Vulkem 950NF, repeat the procedure in 6.6.3. Allow this additional coat of Vulkem 950NF to cure about 2 to 4 hr during ideal ambient temperatures and relative humidity. Proceed to Step 6.8 TOP COAT.

Note: Differences in silica sand mesh size may be approved by your local Tremco sales or technical representative.

- 6.7 Immediately following the application of the Vulkem 950NF as indicated in 6.5 or 6.6, broadcast to refusal (flood coat) the material with 0.6 to 1.2 mm (16-30 mesh) sized silica sand. Allow the application to cure about 8-16 hrs during ideal ambient temperatures. Before proceeding, sweep or blow off any excess sand and proceed to Step 6.8 TOP COAT.
- 6.8 TOP COAT: Note: When mixing Vulkem 951NF Part B must be well shaken prior to mixing with Part A. Apply Vulkem 951NF Top Coat with a medium-nap, solvent-resistant roller sleeve at a rate of 133 ft<sup>2</sup>/gal or 12 wet mils. Note: The textured properties of the finished deck coating system aid in the system's wear and slip resistance. Tremco recommends a test patch to be completed by the applicator and customer acceptance obtained prior to the application.

---

## 7. CLEAN UP

- 7.1 Clean all adjacent areas to remove any stains or spills with Toluene or Xylene.
- 7.2 Clean tools or equipment with Toluene, or Xylene before material cures.

7.3 Clean hands by soaking in hot, soapy water then brushing with a stiff bristle brush.

## 8. MATERIAL USAGE GUIDELINES

**Dymonic 100:** For a 1" (25.4 mm) cant bead over a 1/4" (6 mm) backer rod, 1 case of sealant for every 48 lf (14.8 M) is required.

**Vulkem 350FC Base Coat:** When applied at 64 ft<sup>2</sup>/gal (1.6 M<sup>2</sup>/L), will yield a mil thickness of 25 wet mils.

**Vulkem 950NF Wear Coat:** When applied at 133 ft<sup>2</sup>/gal (3.3 M<sup>2</sup>/L), will yield a mil thickness of 12 wet mils.

**Vulkem 951NF Top Coat:** When applied at 133 ft<sup>2</sup>/gal (3.3 M<sup>2</sup>/L), will yield a mil thickness of 12 wet mils.

**Aggregate:** Approximately 15 to 18 lb. of approved aggregate will be used with each gallon of Vulkem 950NF as prescribed in Section 6.

Due to the number of variables present related to aggregate broadcast method and topcoat application technique coverage rates may vary.

## 9. TROUBLESHOOTING

This section describes common industry application issues when certain environmental conditions exist. Below are some commonly seen issues and remedies. If any of these should occur, it is always recommended that you contact your local Tremco Sales Representative or Tremco Technical Services.

9.1 **Tremco requires that any possible recoating job be reviewed and approved by your Sales and/or Technical Representative prior to installation.**

9.2 For any restoration opportunity or application, compatibility and adhesion testing need to be completed in the field.

9.3 When a deck contains too much moisture, the moisture may change into a vapor, which then condenses at the concrete/membrane interface before the coating has cured and may cause blisters or bubbles, ultimately interfere with proper adhesion. If this should occur, the blisters can be cut out, allowing moisture to escape. After moisture has escaped and the surface is dry, the area can be repaired.

9.4 If the coating application has been installed at a thickness that is greater than directed in our installation instructions, pinholes, blisters or bubbles may occur in the coating. To avoid this occurrence, the material should be applied in accordance with the installation instructions

9.5 If the coating is applied in very hot ambient temperatures, the air in the small spaces between the concrete particles increases in volume and forms blisters. Contact Tremco Technical Services should this occur.

9.6 If the previous coating application has not fully cured, solvent may become trapped between the coats and lead to large blisters that will most likely be tacky on the backside. Blisters may be cut out and repaired after the surface has been allowed to fully dry.

**This section discusses the impact of applying these coatings outside the ideal temperature application range of 65 to 85 °F (18.3 to 29.4 °C) at 50% RH.**

9.7 At temperatures lower than the ideal range, the material will become more visous and it will cure at a slower rate. Refer to the chart below for approximate cure rates at varying temperatures.

## 10. WEATHER IMPACT ON COATING APPLICATIONS

10.1 Deck temperatures may affect cure rates even when ambient temperatures are high.

10.2 Enclosed areas may slow the cure rate of the coating because humidity levels tend to be low in these conditions due to the low exchange of air over the membrane.

10.3 In extremely dry conditions, with RH less than 50%, even when temperatures are high, cure rates can still be extended.

### QUICK REFERENCE APPLICATION CHART

LAYER	PRODUCT	WET MILS	CURE TIME*	SQUARE FEET PER GALLON
Base Coat	Vulkem 350FC	25	3 to 4 hours	64
Wear Coat #1 (drive lanes, ramps, turns, ticket areas)Wear Coat #2 (entire deck	Vulkem 950NF	12	2 to 4 hours	133
Top Coat	Vulkem 951NF	12	2 to 4 hours	133

\*Cure times are based on ideal ambient temperature at 50% RH. See chart below for ideal temperature range.

## APPROXIMATE CURE TIME IN HOURS AT 50% RH

TEMPERATURE AT 50% RH	VULKEM 350FC	VULKEM 950NF	VULKEM 951NF
40°-50 °F 4.4°-12.8 °C	5 to 6 hours	48 to 72 hours	48 to 72 hours
55°-65 °F 12.8°-18.3 °C	3 to 4 hours	6 to 8 hours	6 to 8 hours
65°-85 °F 18.3°-29.4 °C	1.5 to 2.5 hours	2 to 4 hours	2 to 4 hours
85 °F 29.4 °C	1.5 hours	< or = 2 hours	< or = 2 hours

Variations in temperature and humidity can affect the cure rate of the coating. The above chart should be used as a guide only to determine the approximate rate of cure. Other factors can also influence the cure rate such as substrate temperature and enclosed environments. For more information about proper application procedures please refer to the installation instructions or contact Technical Services

V350FC950NF951NF-AI/0923

Tremco Construction Products Group (CPG) brings together Tremco CPG Inc. and its Dryvit and Nudura brands; Willseal; Prebuck LLC; Tremco Barrier Solutions, Inc.; Weatherproofing Technologies, Inc. and its Pure Air Control Services and Canam Building Envelope Specialists offerings; and Weatherproofing Technologies Canada, Inc.



tremcosealants.com | 800.321.7906



Construction Products Group

3735 Green Rd. | Beachwood, OH 44122  
800.321.7906 | tremcocpg.com