

Technical Information Sheet



SkyScape™ Slope Cleats

Item Description

Slope Cleats

Description

The SkyScape Slope Cleat helps stabilize SkyScape Growing Media at slopes greater than 2:12 or 10°. Each Slope Cleat features preformed hooks at both ends which easily clip into the SkyScape Geogrid.

Method of Application

1. Starting at the highest point of the roof, set a row of cleats at the distance shown on the spacing guide located below. Clip each hook at the end of the cleat into the SkyScape Geogrid.
2. To help with growing media stabilization, offset the next row by starting the first cleat with its outside end directly underneath the midpoint of the row above.
3. Repeat the row spacing and offset to the lowest point in the roof.

Storage

- Deliver and store products in original packaging with manufacturer's labels and materials list intact and signed off.
- Store products in designated weather protected areas, elevated from ground, and protected from environmental damage.

Shelf Life

Indefinite

Coverage Rate

Slope	Cleat Spacing
2:12 to 3:12 (10° to 14°)	50" (1.27 m)
3:12 to 4:12 (14° to 18°)	40" (1.02 m)
4:12 to 5:12 (18° to 23°)	30" (762 mm)
5:12 to 6:12 (23° to 26°)	20" (508 mm)
6:12 to 7:12 (26° to 30°)	10" (254 mm)

Clean-Up

- Gather and dispose all debris upon completion of work.
- Clean all surfaces and inspect final assembly for approval.

LEED® Information

Post-Consumer Recycled Content: 0%
Post Industrial Recycled Content: 100%
Manufacturing Location: Murfreesboro, TN

NOTE: LEED® is a registered trademark of the U.S. Green Building Council

Typical Properties	
Property	Value
Dimensions	28½" x 3⅛" x 2⅜" (724 mm x 79 mm x 60 mm)
Material	Recycled ABS Plastic

Please contact Holcim Technical Services at 800-428-4511 for further information.

This sheet is meant to highlight Elevate products and specifications and is subject to change without notice. Holcim takes responsibility for furnishing quality materials that meet published Elevate product specifications or other technical documents, subject to normal manufacturing tolerances. Neither Holcim nor its representatives practice architecture. Holcim offers no opinion on and expressly refuses any responsibility for the soundness of any structure. Holcim accepts no liability for structural failure or resultant damages. Consult a competent structural engineer prior to installation if the structural soundness or structural ability to properly support a planned installation is in question. No Holcim representative is authorized to vary this disclaimer.